



MA-6

Single-head automatic embroidery machine

A whole new world of
embroidery will unfold
before your eyes



SWF

SUNSTAR CO., LTD.

Head office #178-67, GAJWA-DONG, SEO-GU, INCHEON, KOREA
tel +82(0)32 580 5980~93 fax +82(0)32 579 8350~51 www.sunstar.co.kr



For W24H service,
www.swf-service.com

Functions

- Origin return
- Float stitch function
- Frame backward
- Automatic trimming
- Automatic upper/lower thread break sensing
- Auto return to the embroidery position after sudden power interruption
- Edit function
- The cause for stop of the machine is displayed on the screen
- Setting speed and current speed are displayed at R.P.M on the screen
- Setting of frame movement speed
- Remained memory capacity is displayed on the screen
- Compatibility of binary/tertiary data code
- Other code auto sensing
- USB memory stick
- Frame center moving
- Frame semi-auto sensing(Hoop select)

Specifications

Embroidering Range [X x Y]mm		Normal		310 x 180
		Inner Space	Wide Cap Frame	360 x 75
			Semi Wide Cap Frame	180 x 83
			Tubular Frame	310 x 180
Machine Size[L x W x H]mm				870 x 689 x 736
Machine Size[L x W x H]mm (Table Stand)				870 x 689 x 1,506
Speed		Max. 1,000 rpm		
Stitching Length		0.1 ~ 12.7 mm		
Motor	Main	BLDC Motor x 1		
	X-Y	Pulse Motor x 2		
Electricity		1-Phase Free Voltage[100 ~ 240V] / [50/60Hz]		
Power Consumption		500 W		
Bobbin Winder		Option		
Operation Box		Standard : Color Graphic LCD Screen		
Hook		Standard Hook		
Memory Capacity		Max. 3,300,000 stitches		
Memory Media		USB Memory Stick		
Safety Device		Standard : Emergency Stop, Error Code Message		
Optional Device		Cap Frame[Semi/Wide]		

Features

- High Productivity - 1,000RPM
- Elegant Design
- Compact Size & Wide Embroidery Range
- Support Wide Cap Frame
- Laser Pointer
- Lettering Function (15 Fonts)
- Simple Packaging

Technology



• Operation Box

- 6.4in. Graphic LCD screen
- USB Port support
- Key-type user Interface
- LAN Port added for network
- USB Slave Port added for PC connection
- Clean screen composition (High resolution)



• Head & Thread Tension Unit

- Advanced smooth thread way provides efficiency of work

Overseas network

USA

| SUNSTAR U.S.A. INC |

11475 N.W. 39th St. Miami, Florida, 33178, USA
tel: 1-305-591-9596 fax: 1-305-591-0661

CHINA

| FOSHAN SUNSTAR PRECISION CO., LTD. |

China's Nanhai District, Foshan City,
Guangdong Province,
Songgang Shishan Town Industrial Zone,
on the sand the water
tel: 86-757-8520-7222 fax: 86-757-8523-0468

EUROPE

| SUNSTAR MACHINERY EUROPE GMBH |

IZ NOE-SUED - Strasse 7, Obj. 58/D3 A-2355
Wiener Neudorf, Austria
tel: 43-2236-660-229 fax: 43-2236-660-2293

EGYPT

| SWF CAIRO BRANCH OFFICE |

tel: 20-2-2702-0772 fax: 20-2-2702-3859

TURKEY

| SWF TURKEY (ISTANBUL BRANCH OFFICE) |

tel: 90-212-438-1525/1530 fax: 90-212-438-1546

SAUDI ARABIA

| SWF JEDDAH OFFICE |

tel: 966-2627-0589 fax: 966-2647-7164

PAKISTAN

| SWF LAHORE BRANCH OFFICE |

tel: 92-322-4887443

BANGLADESH

| SWF DHAKA BRANCH OFFICE |

tel: 88-02-881-9153 fax: 88-02-883-5707

SYRIA

| SWF ALEPPO BRANCH OFFICE |

tel: 963-21-267-6590 fax: 963-21-264-4978

INDIA

| SWF BANGALORE BRANCH OFFICE |

tel: 91-80-4152-4101 fax: 91-80-4152-4103

| SWF DELHI BRANCH OFFICE |

tel: 91-12-0426-0733 fax: 91-12-0426-0734

| SWF SURAT BRANCH OFFICE |

tel: 91-26-1308-0737 fax: 91-11-4050-3634

VIETNAM

| SWF HOCHIMINH BRANCH OFFICE |

tel: 84-8-3592-1588/84-8-3504-3472 fax: 84-8-3592-1587

| SWF HANOI BRANCH OFFICE |

tel: 84-4-8587-2751/84-4-3783-4532 fax: 84-4-3783-4533

INDONESIA

| SWF JAKARTA BRANCH OFFICE |

tel: 62-021-451-3601~2 fax: 62-021-451-6552